

Pairing steps for multi-monitor system

1. Please prepare 2 tools in advance



1) **A cross screwdriver**, use to remove and install the screw on camera





2) **A thin rod**, use to press the pairing key. You can use a toothpick.



2. Connect the camera and monitors to power

3. Remove the screw from camera. Keep the screw, you will need it later.



4. Choose the monitor which need to pair. Enter the menu, choose the  icon, press , then the monitor start to count.



5. During the counting, press the pairing key on camera.

Pairing key is under the screw you just removed. When you use a tool to press the key (Just click once, and loose immediately, no need long time press), you can clearly feel the pairing key move down then bounce back.



6. A few seconds later, the monitor will pair successfully, and shows the image.

7. Don't forget to install the screw you just removed. It is important for waterproof.

Note: For this system, you will find the monitors show RX1, RX2, RX3, RX4 . When pairing, this letters shows up in turns. For example,If you already get a RX1 in this system, now you pairing a second monitor to this system, the second monitor will show RX2, if you pair the second monitor again, now it becomes RX3, and if you pair the second monitor third time, the monitor shows RX4.